



DTH880

Temperature & Humidity Tester

THE TEMPERATURE AND HUMIDITY EXPERT!

- Temperature from 32° to 122°F (0° to 50°C)
- Humidity from 25 to 95% RH
- Comfort zone indicator
- Displays relative humidity and temperature at the same time
- MIN/MAX Record
- Data Hold



DTH880 • Temperature & Humidity Tester


The DTH880 mounts easily on walls or sits on flat surfaces using its built-in easel stand. Use the DTH880 at home or business. Ideal for use in computer rooms, laundry rooms, shops, offices and greenhouses.

The DTH880 has the following features:

- Temperature in °F or °C (32° to 122°F / 0° to 50°C)
- 25 to 95% relative humidity (RH)
- Comfort zone indicator
- Displays relative humidity and temperature at the same time
- MIN/MAX record
- Data hold
- One year limited warranty

Specifications

Temperature range	32° to 122°F (0° to 50°C)
Resolution	1°(F/C)
Accuracy	±2°F, 32° to 104°F (±1°, 0° to 40°C) ±4°F, below 32° and over 104°F (±2°C, below 0° and over 40°C)
RH range	25% to 95% RH
Resolution	1% RH
Accuracy	±5%, 40% to 80% RH, between 59° and 104°F, 15° to 48°C ±7%, below 40% or over 80% RH, between 59° and 104°F, 15° to 40°C
Battery	1.5 volt AAA (2)



Distributed By:



1-800-547-5740 • Fax: (503) 643-6322
www.ueiautomotive.com
Email: info@ueitest.com

IN CANADA

Vancouver: Phone: 1-877-475-0648 • (604) 278-4511 • Fax: (604) 278-8299
Toronto: Phone: 1-877-475-0648 • Fax: (905) 238-5117

IN EUROPE

Phone: +44 1707 375550 • Fax: +44 1707 393277

